

MILENCO LIMITED

Bumper Protector Fitting Instructions

- Step 1** Thoroughly clean the area to which the Milenco Bumper Protector is to be applied, by using white spirit or petrol to ensure all wax polish is removed before application.
- Step 2** Carefully measure position and mark out with masking tape.
- Step 3** Wipe area with damp cloth.
- Step 4** Remove backing paper from half of the Bumper Protector, ensuring you do not leave fingerprints on the Bumper Protector.
- Step 5** Apply the edge of the Protector in the marked position. Squeeze out any air bubbles, in a left to right motion, as you remove the rest of the backing paper.

Please keep your Milenco Bumper Protector out of the rain for 24hrs from application.