

Installation & Fitting Instructions

MILENCO

2851 WS3000

Winterhoff Hitchlock



Insert the Security ball and the push handle down into the engaged position



Unlock and remove the locking bolt on the hitchlock



Position the hitchlock body underneath so that the stabiliser bolt is inserted in to the slot on the side



Place the bolt through the hole on the right hand side at the top of the body so that the lock is on the left hand side



Push the 2 sections of the locking bolt together and turn the key to lock the mechanism



The hitch is now secure