

MILENCO

Aero 4 and Aero Platinum Towing Mirrors Fitting (product code 1601/ 2912/ 2073/ 2899/ 1588/ 1595/ 6606/ 6613)

THINK READ PLAN



1. Clean car wing mirror



2. Fit the first mirror clamp, ensuring the wedge is fully inserted into the gap between the mirror and the wing mirror housing. Whilst holding the clamp firmly in place, turn screw 1 until the clamp is securely fitted.



3. Repeat step 2 with the second clamp.



4. Insert the mirror arm.



5. Turn screw 2 to hold the arm in place.



6. Repeat step 5 with second clamp.

Please note that if you have our Aero 3 or 4 mirrors you may require different pads for your mirrors depending on what vehicle you have.

*Aero V Pads, Product Code: 3186
2010 onwards Kia Sorento.*

*Aero F Pads, Product code: 4664
post 2013 VW group cars (Audi, Seat and Skoda) .*

*Aero LR Pads, Product Code: 4466
2014 onwards Land Rover Discovery and Range Rover.*

The Aero Platinum and Grand Aero Platinum Mirrors do not require additional pads.

*If you encounter any issues with this product then please email enquiries@milenco.com
or call 01908 220 102*